


Pictures of components CC-series part 1

For your information: The 4 digits numbers like C008 or C036 are not INDUTHERM order numbers. They are the drawing position numbers and shall help you to find this article in the assembly drawings and spare parts lists in your manual. INDUTHERM order numbers have 8 digits!



crucible
for round die

C008



crucible
for round die

C008




die for wire with round
outside shape

C044




die for tube

C044




die for sheet with
rectangular outside shape

C044



die for 5 wires with rec-
tangular outside shape

C044



ball for
sealing rod

C052



graphite
sealing rod

C035



crucible shield

C011



crucible bottom insula-
tion for rectangular die

C022



crucible bottom insulation
for round die

C022



insulation for round die

C045



crucible
press gasket

C050



ceramic sealing rod
for ball

C051



thermocouple up to 1300°
for wall measurement
pink colour

C036



thermocouple up to 1200°
for center measurement
green colour

C039



thermocouple up to 1600°
for wall with 4mm cera-
mic orange colour

C071



ceramic cover
for thermocouple

C034



crucible tongs

C059




adhesive
for high temperature

C115



lubrication for sealing
rod holder

C116



starter bar for sheet

C049




starter bar
for different heads

C049



GSM modem for remote
service

C106



CD-Rom with Videos

C164

Please order the spare parts list plus the drawing for *your* machine at RG@indutherm.de
For the correct list, we need to know your machine type and the serial number of your machine.

Pictures of components CC-series part 2

For your information: The 4 digits numbers like C008 or C036 are not INDUTHERM order numbers. They are the drawing position numbers and shall help you to find this article in the assembly drawings and spare parts lists in your manual. INDUTHERM order numbers have 8 digits!




draw roll

C043



starter bar head for tube

C048



window

C016



sealing rod holder
new type

C017



spring

C090



handle for bell

C021



holder

C091



flow meter for water

C087



manometer
for draw roll pressure

C095



sealing
rod cylinder

C096



o-ring
inductor housing

C019



die temperature sensor

C047



screw

C037



sensor for water

C097

For older machines:



clamp for sealing rod

C092



flow meter
for protective gas

C088



panel printer
cartridge

C104